DOOR AND PANEL PARTS

UNDERCOUNTER DISHWASHER

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)

MAYTAG®



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10290309	Instructions, Installation
	W10398587	Energy Guide
		Use & Care Guide
	W10240116	English/French
	W10240117	Spanish
	W10142800	Tech Sheet
2		Arm, Hinge
	W10143374	Left
	W10143373	Right
3	8268983	Stiffener, Door
4		Panel Front (Includes Items 13,15,17)
	W10240088	Black
	W10240089	White
	W10240091	Stainless
	W10240090	Bisque
5	W10195777	Access Panel
6	8269016	Clip, Grounding
7	W10073520	Insulation, Door
8	W10205336	Toe Panel
9	W10073540	Insulation, Toe Panel
10	302868	Screw
11	304392	Screw
12	489470	Screw
13		Vent Assembly
	W10201653	Black
	W10201654	White
	W10201655	Bisque
	W10201656	Stainless
14		Handle
	W10199637	Black
	W10199635	White
	W10249315	Bisque
	W10199639	Chrome
15	8534008	Screw
16	8268961	Sleeve, Friction
17	8564951	Stud, Mounting



Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL AND LATCH PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Console Assembly (Includes Active Overlay & Insert)
	W10240084	Black
	W10240085	White
	W10240086	Bisque
	W10240087	Stainless
2	8546546	Clip, BI−Metal
3	W10285180	Control Electronic
4	W10102497	Switch, Door
5	W10404409	Latch Assembly
6	W10344801	Bi−Metal
7	304231	Screw
8	W10143018	Cover, Control Assembly

INNER DOOR PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10348413	Screw, Door
2	8545608	Harness, Vent Motor
3	8575894	Inner Door
4	W10482094	Cover, Dispenser
5	W10164259	Vent Assembly
6	8269259	Gasket, Vent
7	8575893	Deflector, Vent
8	W10199696	Dispenser, Assembly
9	8269258	Seal, Front
10	W10199683	Cap, Rinse Aid
11	W10413093	Wiring Harness
12	W10177098	Screw
13	8269296	Seal, Console/door
14	W10462232	Bracket, Dispenser

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FILL, DRAIN AND OVERFILL PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8268892	Lever, Overflow Switch
2	8531412	Hose, Inlet
3	W10195536	Water Inlet (Also Order Item 4)
4	8531323	Gasket
5	8531327	Nut, Inlet (Also Order Item 4)
6	8269146	Clamp, Hose
7	W10195049	Fill Valve Assembly
8	304392	Screw
9	356138	Clamp, Hose
10	W10137608	Drain Loop with Check Valve
11	W10102495	Switch, Overfill
12	W10175383	Standpipe, Overfill
13	8268895	Float & Retainer Assembly
14	W10292152	Miscellaneous Parts Bag (Includes 2 Screws, 2 Hose Clamps & 2 Undercounter Brackets)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB AND FRAME PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB AND FRAME PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10254859	Tub Assembly (Includes Heater Assembly)
2	8269831	Wheel Leg
3	W10284090	Door Seal
4	W10317686	Strike, Latch
5	3378595	Bracket, Thermostat
6	W10339699	Shield, Thermostat
7	W10341745	Screw
8	8268990	Bushing, Door Spring
9	3367670	Screw
10	8269145	Bracket, Undercounter
11	661566	Thermostat
12	3378128	Washer, Pronged
13	3400014	Screw
14	8524584	Leveler, Leg
15	W10165274	Screw
16	8524473	Spring, Door Balance
17	8575897	Wheel & Mount Assembly
18	W10231537	Screw
19	8268991	Cover, Terminal Box
20	8573240	Shield, Sound Tub
21	W10337661	Strain Relief

PUMP AND MOTOR PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PUMP AND MOTOR PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1	8534952	Accumulator Assy
2	8283527	Shield, Motor
3	W10348405	Screw
4	8572618	Sump with seal
5	8268375	Check Valve, Sump
6	W10083957	Chopper Assembly
7	9741232	Screw
8	8531857	Protector, Inlet
9	W10231537	Motor Assembly
10	3400217	Screw
11	W10084567	Screen, Separation
12	W10298344	Sump & Motor Assembly
13	W10300599	Tab, Sump
14	8533949	Nut
15	8558995	Pump, Drain
16	W10142656	Volute W/ Seal (Also Order Items 19 & 21)
17	8269144	Hose, Drain
18	W10200940	Motor
19	8531018	Washer
20	8531017	Impeller Kit (Also Order Item 19)
21	8268403	Face Seal Assembly (Also Order Item 19)
22	356138	Clamp, Hose
23	W10134017	Optical Water Indicator
24	W10334457	Capacitor

UPPER WASH AND RINSE PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8559848	Feed Tube Silverware Zone (Also Inc. #3)
2	W10349488	Screw
3	8557720	Spinner, 3rd Level Wash
4	W10199810	Manifold
5	W10199808	Mount,Spray Arm
6	8268433	Seal, Sprayarm
7	8269295	Nozzle−Feed
8	W10082841	Spray Arm
9	W10118464	Retainer, Push−In
10	W10199809	Hanger

HEATER PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10134009	Heater Element Assembly (Also Includes Item 2)
2	717273	Washer, Heater Element
3	8268548	Nut, Heater Element
4	8269262	Bracket, Heater Support
5	W10343251	Shield, Heater Nut

NOTE: If heater element is removed, it must be replaced.

UPPER RACK AND TRACK PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10240139	Dishrack, Upper
2	8565925	Stop, Track Non−Removable
3	W10254909	Wheel
4	3385089	Track, Rack
5	W10306231	Track, Spacer
6	W10289765	Shelf, Cup
7	W10372814	Clip, Lite Item

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER RACK PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10199774	Dishrack, Lower
2	W10082868	Wheel & Transport Assembly
3	W10199701	Silverware, Basket Assembly
4	W10199681	Lid, Silverware Basket
5	W10401484	Cup Shelf Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER WASHARM PARTS

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10330588	Wash Arm Assembly
2	8268343	Cap, Internal Rear Feed
3	8268340	Seal, Sprayarm
4	W10077898	Support, Lower Sprayarm

OPTIONAL PARTS (NOT INCLUDED)

For Models: MDBH969AWB1, MDBH969AWW1, MDBH969AWQ1, MDBH969AWS1
(Black) (White) (Bisque) (Stainless)

Illus. No.	Part No.	DESCRIPTION

ACCESSORIES

Side Panel Kits
- 8171656 White
- 8171657 Black
- 8171658 Biscuit
- 8171659 Stainless Steel

Custom Panel & Trim Kit
- 8171555 Black
- 8171556 White
- 8171557 Biscuit
- 8171558 Grey

Moisture Barrier Kit
- 4396277 Kit

Drain Hose
- 3385556 12 Ft.

Seal Kit
- 6−919539 Metal Chopper

PAINT, TOUCH−UP (1/2oz.)

- 72017 White
- 72032 Black
- 4392899 Biscuit
- 4396603 Meteorite

PAINT, PRESSURIZED SPRAY (12 oz.)

- 350930 White
- 285006 Superior Black
- 4392901 Biscuit

PAINT, BULK (1 qt.)

- 799344 White (Uncut)
- 4392900 Biscuit

POWER CORD KIT

- 4317824 Power Cord Kit (Includes Power Cord & Misc. Hardware)

ANTI−TIP KIT

- 8171477 Floor Mount Kit

DISHRACK REPAIR

Tip Tine Repair Kit
(Enough for Two Complete Dishracks)
- 4396838 White
- 4396840 Grey

Vinyl Touch−Up (4 oz.)
- 676453 White
- 676455 Grey